


# Facilities Management

**POLICY:**

**CONFINED SPACE**

*E. Kusche*





# Facilities Management

**POLICY:**

**CONFINED SPACE**

**NUMBER:**

---

**POLICY:**

**CONFINED SPACE**

**NUMBER:**

S-8

## CONFINED SPACE GAS MONITOR OPERATION

UNITS WILL BE SITTING ON THE CHARGER IN THE TOOL CRIB WHEN NOT IN USE.

**GREEN LIGHT** INDICATES A FULL CHARGE.

BEFORE USE, ENSURE THAT THE UNIT IS CALIBRATED ON THE GALAXY UNIT AND REGISTERS IF IT REGISTERS . **DO NOT USE**

1. Press on/off button on side of unit.
2. Wait for self test to finish (takes approximately 2 minutes).

:

O2 @ 20.8	LEL @ 0	CO @ 0	H2S @ 0
-----------	---------	--------	---------

1. Push and hold reset on the side of the unit
2. Unit will ask for zero calibration : push **on/off** button once.
3. Unit will ask for span calibration: **do not** push any buttons – **wait**.

### **UNIT IS READY FOR USE:**

Complete the Confined Space Entry Permit. Indicate which unit is used by **Serial Number**. Leave unit and pump on for entire entry.

### **ALLOWABLE LEVELS**

<b>OXYGEN - 19.5 23 %</b>	<b>CO (carbon monoxide) - 0 25 ppm</b>
<b>LEL (lower explosive level)</b>	<b>H<sub>2</sub>S (hydrogen sulphide)- 0 - 10 ppm</b>
<b>0 - 5% FOR HOT WORK</b>	

### **IF SENSOR ALARM SOUNDS:**

1. **Get out immediately.**
2. Check instrument for obvious faulty conditions.
- IF ALARM CONTINUES:**
3. Identify cause of alarm (flashing numbers on screen indicates which sensor is in alarm) and correct if possible.
- 4.

**APPENDIX 1**